


## Quick-guide for Luma counter artwork.

- 1) Download the layout-guides and mediaspecs. at our website:  
[http://www.aaadisplay.com/Pages/systemen/luma\\_documenten.html](http://www.aaadisplay.com/Pages/systemen/luma_documenten.html)
- 2) Open the document for your selected Luma counter, large or small.
- 3) Place your artwork in a layer under the white spot colour (illustrated as magenta), and under the black cover-bars




The white layer (Spot) is printed behind the artwork, but must be placed in front. Printer RIP dependent.

The black cover-bars (Black) serve to dim the light inside the counter in specific areas.

Your main message / logo will be presented at the front of the counter, as illustrated below.

- 4) Make sure your main message / logo is centered and no wider than 100cm (small counter) or 130cm (large counter)

(Below is illustrated how your layers are stacked)



- 5) Print your Illustrator file to Actobat, using 'press optimized' settings or 'PDF-X3' settings if you have transparency in your artwork. Send the PDF file to us.

(Below is illustrated how your final print will appear)

